


How does Drimaster work?

Drimaster works as a 'positive pressure' system, continuously inputting fresh filtered air into your house from outside whilst removing excess moisture from inside.

1. Outside air is drawn into the ceiling space.

2. It is slightly warmed by heat caused from solar radiation and heat loss from the home.

3. This air is drawn into the unit, filtered, then ducted into a central area of the house.



4. This air then mixes with the warmer air that naturally accumulates at ceiling level.

5. Air continuously and gently dilutes, displaces and replaces the air within your home, resulting in a clean and healthy environment.